


# QUICK START GUIDE

## TX UNIT

AUX In for USB  
Chat cable

Optical In from  
TV or console



Optical Out to  
home theater

Dual USB  
[for future accessories]



Power / Pairing

Dolby® On / Off

## RX UNIT

Headphone

Xbox Live®  
Controller cable



Power / Charge\*



Power / Pairing  
Battery Level

Bass Expander  
On / Off

\* when using optional Rechargeable  
Battery Pack

**OPTICAL CABLE** 



**POWER ADAPTER** 

**XBOX® CHAT CABLE**   
[connect to controller for Xbox Live® Chat]

**PLAY / CHARGE CABLE**   
[connect to console for RX power if needed]


## PAIRING PROCESS


Tx and Rx come pre-paired. Do not initiate pairing process unless you cannot hear game audio after completing setup.


1. Hold  power button on TX until it blinks white then release. TX is now in pairing mode.
2. Next, hold  power button on RX until it blinks white then release. RX is now in pairing mode.
3. Both devices will confirm they are paired when the LED's are solid white for 3 seconds.
4. When pairing is complete, both TX / RX power buttons will turn solid red.



## POWER INDICATORS ON RX

 **Solid Red**  
Fully charged  
or USB powered

 **Blink Red  
+ Audible BEEP**  
Need juice  
<10% charged

 **Solid Orange**  
Charging Li-Ion  
battery only

## OPTIONAL USB CHAT CABLE (SOLD SEPARATELY)




PS3™ console

AUX In



## RECHARGEABLE BATTERY PACK (SOLD SEPARATELY)



Remove AAA tray  
Insert battery pack  
Charge RX via  
Play / Charge cable